

## Using with General Music Player

You can enjoy the stereo music transmitted wirelessly from the music player which is installed the i-PHONO PLUS Bluetooth Stereo Dongle (P/N: BT430Tx), the music player can be a CD Player, MP3 Player, Mini Hi-Fi system, Handheld Game ConSOLE, Portable Media Player, Non-Bluetooth supported computer, etc.

### < Via i-PHONO PLUS Stereo Dongle >

**Step-1:** Put the i-PHONO PLUS headphone in the pairing mode in advance. (page14)

**Step-2:** Afterward, put the i-PHONO PLUS stereo dongle in the pairing mode. Turn on the stereo dongle, then press and hold the Pairing Button until its Status Indicator flashes Blue and Red alternately. Once the stereo dongle is putting in the pairing mode, it will begin to search and pair with the headphone automatically. After the pairing is completed, both the devices' Status Indicators will flash Blue regularly.

**Step-3:** Install the stereo dongle to the music player. The installation is effortless and no driver or software is necessary. You only need to connect the Stereo Plug of the i-PHONO PLUS stereo dongle to the 3.5mm (1/8 in.) stereo-out jack of the music player.

**Step-4:** Play Music.

**Notice:** After you connected the headphone with the stereo dongle at the first time, please adjust the headphone volume up due to the initial volume of the headphone volume is minimum.

