

Pairing i-PHONO PLUS Headphone

Before you start to use the i-PHONO PLUS headphone with the compatible Bluetooth device such as a stereo dongle, computer, mobile phone, PDA, etc., please pair the headphone with the compatible Bluetooth device in advance.

Step-1: If the headphone is already on, please disconnect all Bluetooth services between the headphone and other devices. Then, turn off the headphone.

Step-2: Turn on the headphone. Then, press and hold the Multi-functional Button of headphone for 2 seconds, and the Status Indicator of headphone will flash Blue and Red alternately; meanwhile, the headphone is in the pairing mode.

After the pairing is completed, the Status Indicator of headphone will flash Blue regularly.

